

*Change for the better*

**UTIER**  
**PACK**



***DZ(Q)-600T***

*Desktop External*



## *DZ(Q)-600T*

### *Desktop External*

This machine is external-type horizontal vacuum packaging machine and is not subject to the restriction by size of its vacuum chamber. It can be used directly for vacuum (gas flushing) packing of the products. It can keep the products fresh, maintain original taste and prevent them from mildew, decay and dampness in order to prolong the storage period or shelf life of products. This type of packaging machine is applicable for protecting electronic products from dampness and oxidizing discoloration (such as semiconductors, crystals, TC, PCB and metal workpieces) as well as fresh-keeping packaging of fruits, foods, vegetables and seafood.

#### SUITABLE PRODUCT

Fruit, vegetable, food pack  
Medical products (pill, syringe, bandage)  
Electrical products (PCB board, control panel, micro-chips etc)  
Cheese pack  
Dates pack  
Meat pack  
Chemical material pack  
Metal or other material components  
Electrical strip roll  
etc...





## FACTS

Capacity: 2 packs/min

Use: For pack food product, medical product and other middle size product. It is easy to move and do not use much of space. The stainless steel surface will be very easy to clean. And also provide a strong structure stress.

Benefit:

Aluminium sealing bar will be very sustainable to use. The 304 stainless steel makes the machine very sustainable and ease to clean.

## How it works

DZ(Q)-600T is the upgraded type of DZ(Q)-400T which means they have a similar working method and function.

The DZ(Q)-600T can seal larger plastic bag than DZ(Q)-400T. Also with a large inner side makes it can contain larger vacuum pump which provide a better vacuum and gas flush effect.

The control panel is similar with DZ(Q)-400T which includes a PCB control panel, power switch, power lamp, starting switch, emergency switch and a vacuum meter.

The control panel have 9 memory programs. Set the vacuum degree, heating time and cooling time before sealing the bag. After that press the pedal switch to start working or just press the starting switch on the control panel. After the sealing process, the sealing bar will release and check the sealing effect.



# Parameter

|                |                        |
|----------------|------------------------|
| Model          | DZ(Q)-600T             |
| Power          | 220V/AC,50Hz           |
| Sealing Length | 600mm                  |
| Sealing Width  | 10mm                   |
| Vacuum         | $\leq -0.08\text{MPa}$ |
| Air Source     | More than 0.5 MPa      |
| Size           | 750mmx840mmx1000mm     |
| Weight         | 110kg                  |



Utien Pack Co., Ltd  
255 Shuguang Rd,  
Kebei Industrial Zone,  
Shaoxing, Zhejiang 312081,  
China  
Tel:+86 575 8110 7017  
Fax:+86 575 8110 7023  
Web:www.utien.com  
e-mail:export@utien.com

**UTIEN  
PACK**